
## PLUMBERS TEMPORARY CONTINUITY BONDS

When working with Metallic water and gas services. Plumbers can get an electric shock if there is a fault in the electrical supply system on the premises or in the street. Current will flow in the earth wire and onto water and gas piping system. Making it live which can cause a serious or fatal electric shock. It is recommended a temporary bridging or temporary continuity bond. Is applied to both sides of the pipe being cut and kept in place until the work is complete. EFO Plumbers temporary continuity bonds fit a range of pipe sizes. Electrical insulated gloves should also be used when applying the temporary continuity bonds.





## PLUMBERS TEMPORARY CONTINUITY BOND

**SKU: PTCB** 

When working with Metallic water and gas services, plumbers can get an electric shock if there is a fault in the electrical supply system on the premises or in the street. Current will flow in the earth wire and onto water and gas piping system making it

Read More

